



Phone: 262-692-2214 / Fax: 262-692-9780

## COUNTERTOP INSTALLATION REQUIREMENTS

Please review the following requests that are needed prior to our install:

- All cabinets must be level for seaming purposes.
- Wall cleats need to be installed between spaces with no cabinets (lazy-susans, etc).
- All plumbing and electrical involved needs to be disconnected before we install and reconnected after install (we are not contracted for any plumbing or electrical services).
- We need to have the following items on the job-site prior to installation: sinks, faucets, soap dispensers, air gap, (dishwasher), hot water faucet, etc. this will allow the correct holes to be drilled.
- Please complete the Faucet-Accessory Drilling Location Form for the faucet, air gap, soap/water dispensers, etc. prior to install date.
- All ranges, cooktops, slide-ins, dishwashers, etc. need to be on the jobsite, we fit appliance with cutouts.
- Sinks need to be on job-site (if we do not already have them at our shop).
- Remove drawers out of cabinets, as well as pots and pans from cabinets.
- Remove refrigerator (unless it is built into a cabinet) and stove from kitchen.
- Have pathways clear from entryway to work area. Counters are heavy and somewhat large, clear pathways allow us to move freely.
- Any glue left behind after countertop removal must be cleaned from cabinets (Uhligs will take care of, if contracted for removal of existing tops).
- If existing tops are not removed by install date, we will remove them for a charge (We do not dispose of existing tops).
- If the above is not completed, the job will need to be rescheduled. A second trip will be charged. Please note our installation schedule books 2 or 3 weeks in advance.

Uhlig Custom Counters, Inc. thanks you for helping our installation run smoothly.